



# Easy Conversion Chart:

## BE1-CDS220 to BE1-11t

This simple chart is designed to help you choose the appropriate BE1-11 style configuration with the same minimum coverage as your BE1-CDS220. Just match up the color-coded options on the left (BE1-CDS220) with those on the right (BE1-11t). Options colored black require no selection. For reference, see the product spec style charts on Page 2.

For assistance, contact technical support at 618-654-2341.

**Enter your BE1-CDS220 style configuration below to generate new BE1-11 style configuration**

From	BE1-CDS220 Style Configuration						To	BE1-11 Style Configuration					
	Mounting	Cover	Load Profile	RS-485 Port Protocol	Front Panel	Power Supply	Ethernet Protocol	Network Connections	Option 1	Inputs/Outputs	Case	Firmware	
Current Sensing	A <sup>1</sup> B D <sup>1</sup> E F	0	E	N	0	Y	E <sup>1</sup> E D <sup>1</sup> D D	2 2 6 6 6	3 1 2	N <sup>3</sup> M D	0 <sup>3</sup> 0 <sup>3</sup> 0 <sup>3</sup>	00	
No Option	No Option	No Option	No Option	No Option	No Option	No Option	No Option	No Option	No Option	No Option	No Option	No Option	
Input/Output													
Current Sensing													

**BE1-CDS220**

**Enter your current BE1-CDS220 configuration below**

BE1-CDS220	0	E	N	0	Y					J	2	P	0	E	0	00
------------	---	---	---	---	---	--	--	--	--	---	---	---	---	---	---	----

**BE1-11**

<sup>1</sup> BE1-11 always comes with neutral CT. Any BE1-11 Ground Current selection is valid for this BE1-CDS220 option.

<sup>2</sup> BE1-11 incorporates each of these options in the standard relay. No selection necessary.

<sup>3</sup> ASCII protocol is not available on the BE1-11. Other Ethernet options available.

<sup>4</sup> BE1-11 does not use front covers for any case styles. No selection necessary.

<sup>5</sup> BE1-11 is available in only a S1-sized vertical mount (J) option.

**DISCLAIMER:** Some options for the BE1-11 have been preselected in the above guide. To insure accuracy, please verify your style configuration using the BE1-11 style chart on page 2.

### Sample Style Configuration Conversion

BE1-CDS220	BE1-11t
5 amp Phase with 5 amp Ground	E → 6
No Option	0 → D
8 Inputs, 6 Outputs, 1 Alarm	E → 2
No Option	N → M
No Option	O → 0
125/250 Vac/dc PS	Z → J
Six Button HMI with LCD	Y → 1
Modbus over 485	1 → P
None	N → 0
No Cover	O → E
Horizontal Panel Mount	H → 0
	00 → 00
	5 amp Phase
	5 amp Ground
	125/250 PS
	Modbus over 485
	No Ethernet
	J Case
	Standard I/O, N.O. Alarm
	Current Differential
	Copper Ethernet
	Option 3, None
	Option 2, None
	Latest Firmware



